

## Instructions:

- 1 - reboot XL-7/MP-7/P2500 holding down Home/Enter
- 2 - if you already have 1.17, skip to step 6
- 3 - using E-loader, download commandprep10.dli
- 4 - when asked to "Replace bootloader?" press enter
- 5 - when instructed, reboot XL-7/MP-7/P2500, again holding down Home/Enter
- 6 - using E-loader, download command118.dli
- 7 - follow prompts
- 8 - enjoy